


International Advanced School for Muon Spin Spectroscopy
2019.08.20

Internal Magnetic Field in Solids Detected with μ^- SR

Jun Sugiyama
CROSS Neutron Science and
Technology Center

CROSS?

CROSS Neutron Science & Technology Center was established in 2011 to support neutron users in J-PARC.



Japan Proton Accelerator Research Complex

CROSS?

CROSS is now responsible for the following seven neutron instruments.


High-pressure diffraction

Quasielastic
Inelastic

Imaging

Crystal structural analysis

Small angle
Polarized Reflectivity



μ^+ SR & μ^- SR

Advantages of μ^+ SR

- Sensitive to local magnetic environments caused by both nuclear and electron in ZF
- Unique time window covers a gap between neutron and NMR
- Wide momentum range suitable from bulk to film samples
- Sample is not radioactivated

Disadvantages of μ^+ SR

- Muon site is still ambiguous particularly at high temperatures, despite the recent progress of DFT+ μ
- Implanted μ^+ may alter local environments
- Positive muon behaves as a light isotope of proton ($m_\mu = 1/9m_p$) in solids
- May not be suitable for observing hydrogen dynamics

We have μ^- -SR!

Merits of μ^- SR


- Negative muon site is very clear, since it is captured by nucleus; i.e. **at the lattice site**
- Negative muon captured by nucleus is stable even above decomposition temperature of the target material
- Optimal tool for dynamics measurements

Difficulties in μ^- SR

- μ^- behaves as a heavy electron ($m_\mu = 200m_e$) and is captured by a nucleus
 - decrease in spin polarization
- need data with very high statistics



Decrease in Spin Polarization

Decrease in Spin Polarization


 μ^+ SR

Decrease in Spin Polarization

μ^+ SR




Decrease in Spin Polarization


 μ^+ SR μ^- SR

Decrease in Spin Polarization

μ^+ SR




μ^- SR




Decrease in Spin Polarization

μ^+ SR




μ^- SR






Decrease in Spin Polarization

μ^+ SR




μ^- SR






Decrease in Spin Polarization

μ^+ SR



μ^- SR



We need 36 times higher statistics for μ^- SR.


TIME (μ s)

TIME (μ s)

Decrease in Spin Polarization

We need 36 times higher statistics for μ^- -SR.

This is the main reason why the μ^- -SR work eventually disappeared about 30 years ago.



μ^- -SR and related papers

Decrease in Spin Polarization


We need 36 times higher statistics for μ^- SR.

This is the main reason why the μ^- SR work eventually disappeared about 30 years ago.

However, the combination between the intense pulsed muon beam in ISIS and J-PARC and the development of multi-detector counting system has drastically increased the counting rate of μ^\pm SR.

Decrease in Spin Polarization

We need 36 times higher statistics for μ -SR.



ARGUS/ISIS 192ch, D1/J-PARC 640 ch.

Decrease in Spin Polarization

We need 36 times higher statistics for μ^- SR.

This is the main reason why the μ^- SR work eventually disappeared about 30 years ago.


However, the combination between the intense pulsed muon beam in ISIS and J-PARC and the development of multi-detector counting system has drastically increased the counting rate of μ^\pm SR.

This problem has been overcome!

Difficulties in μ^- SR

- μ^- behaves as a heavy electron ($m_\mu = 200m_e$) and is captured by a nucleus
 - decrease in spin polarization
- need data with very high statistics
- μ^- lifetime depends on the nucleus, on which μ^- is captured
- data analysis is not easy


Lifetime of negative muon



Lifetime of μ^- decreases with increasing Z of nucleus on which μ^- is captured


Multi-lifetime Components

μ^+ SR



Multi-lifetime Components

μ^+ SR





ASYMMETRY

$$= (N^F - \alpha N^B) / (N^F + \alpha N^B)$$

Multi-lifetime Components




μ^+ SR



Multi-lifetime Components

μ^+ SR




μ^- SR



Multi-lifetime Components

μ^+ SR

μ^- SR







ASYMMETRY
 $= (N^F - \alpha_1 N^B) / (N^F + \alpha_1 N^B)$

Multi-lifetime Components

μ^+ SR

μ^- SR



Difficulties in μ^- SR

- μ^- behaves as a heavy electron ($m_\mu = 200m_e$) and is captured by a nucleus
 - decrease in spin polarization
- need data with very high statistics
- μ^- lifetime depends on the nucleus, on which μ^- is captured
- data analysis is not easy

Difficulties in μ^- SR


- μ^- behaves as a heavy electron ($m_{\mu}=200m_e$) and is captured by a nucleus
- decrease in spin polarization
- need data with very high statistics
- μ^- lifetime depends on the nucleus, on which μ^- is captured
- data analysis is not easy
- when a nucleus captures μ^- , such nucleus looks like the nucleus with $Z-1$
- comparable to impurity NMR
- high momentum μ^- beam is required
- need a large amount of sample

Merits of μ^- SR

- Negative muon site is very clear, since it is captured by nucleus; i.e. at the lattice site
- Negative muon captured by nucleus is stable even above decomposition temperature
- Optimal tool for dynamics measurements

Thus, we have attempted to measure μ^- SR for a hydrogen storage material, MgH_2 .


First μ -SR Setup



Momentum : 50 MeV/c
Sample size

- $5*5*2\text{cm}^3$
- PET cell
- about 40g

Room temperature



Since MgH_2 is unstable in air, the PET cell was sealed into a plastic bag.

Recent Setup



Momentum : 40 MeV/c
Sample size

- 35mm ϕ * 14mm
- Ti cell
- about 16g

10-450 K

Since MgH_2 is unstable in air, the sample was sealed into a Ti cell with a gold O-ring.

More Sophisticated Setup




Momentum : 62 MeV/c

Sample size

- $5*5*2 \text{ cm}^3$
- Cu cell
- about 51g



Room temperature



In order to avoid μ^- SR signal from the surrounding materials, the Cu cell is set into a Cu holder.



μ^- -SR Spectra for MgH_2

Histogram of Forward (Upstream) & Backward (Downstream) Counters




μ^- SR Spectra for MgH_2

Histogram of Forward (Upstream) & Backward (Downstream) Counters




Consisting of five different lifetime components, such as, μ^- captured by Mg, C, O, Pb, and the other particle.

μ^- SR Asymmetry Spectrum



- Non-linear background signal caused by uneven multi-lifetime components.
- LF decoupling behavior is clearly seen.

Fit the μ^- -SR Spectrum



- subtract a BG signal
- fit in the time domain between 0.2 and 5.5 μ s
- Kubo-Toyabe and exponential decay signals
- such fit provides $\Delta=6.11(8)$ Oe (predicted as 6.82 Oe)

JS et al., *PRL* 121, 087202 (2018).

SUMMARY

- With an intense pulsed muon beam and the development of a counting system, the μ^- SR technique has been reborn in 2018.
- μ^- SR is useful to observe dynamics of H, ion, and light element in solids from a fixed viewpoint.

SUMMARY

- With an intense pulsed muon beam and the development of a counting system, the μ^- -SR technique has been reborn in 2018.
- μ^- -SR is useful to observe dynamics of H, ion, and light element in solids from a fixed viewpoint.
- To know H dynamics as a function of T , μ^- -SR on MgH_2 is still in progress.
- To confirm the absence of breaking of time reversal symmetry, μ^- -SR on MgB_2 is on going.
- To determine the diffusing species, μ^- -SR on LiFePO_4 is also on going.

MESSAGE

Clarify μ^+ SR ambiguity
with μ^- SR!

What μ SR can do by itself has to be done by μ SR.

COLABORATORS

Izumi Umegaki

Wataru Higemoto

Soshi Takeshita

Akihiro Koda

Koichiro Shimomura

Kazuhiko Ninomiya

M. Kenya Kubo

Takehito Nakano

Katsuhiko Ishida

Adrian Hillier

Jess H. Brewer

Toyota CRDL

JAEA

KEK

KEK

KEK

Osaka Univ.

ICU

Ibaraki Univ.

Riken & ISIS

ISIS

UBC & TRIUMF

This work was supported by JSPS KAKENHI
JP26286084 and JP18H01863.

FINIS